

INSTRUCTIONS:

Quick Connect Canopies

Models: QMP-M1RN and QMP-G1RN

CAUTION:

Read all instructions.

Do not conceal or extend exposed conductors through a building wall.

Do not install this system in wet locations.

For low voltage exposed insulated conductor systems required by 30.1© do not install any part of this system less than 7 feet (2.2m) above the floor.

To reduce the risk of fire and burns, do not install this lighting system where the exposed bare conductors can be shorted or contact any conductive materials.

To reduce the risk of fire and overheating, make sure all connections are tight.

Do not install any luminaire closer than 6 inches (15.25 cm) from any curtain, or similar combustible materials.

Turn off electrical power before modifying the lighting system in any way.

SAVE THESE INSTRUCTIONS

Overview: Canopies are designed to fit all WAC quick connect fixtures. They may also be used on other manufacturers brand of quick connect (consult factory for compatibility). Uses a 50 watt max fixture or pendant.

Canopies come with a self-contained electronic transformer that may be dimmed with an electronic low volt dimmer switch.

1. Loosen the three canopy screws and separate the canopy from the base plate.
2. Remove a knock out from the base plate.
3. Support canopy and guide the black and white wires and from the transformer through the knock out in the base plate and into the Junction box.
4. Connect ground wire from junction box to the green grounding wire from the base plate.
5. Connect corresponding line volt wires from the junction box to transformer wires, with wire nuts (supplied). Tuck excess wire into the junction box.
6. Attach the base plate to the junction box using the slotted holes.
7. Raise the canopy to the base plate, and tighten the three screws loosened earlier.

Retain instructions for future reference.

